

# timeware® Bell Driver

## Datasheet for the X-401 bell driver

#### **Overview**

With our introduction of Suprema hardware as the primary source of our 'clocking machines', we have had to change our method of triggering a bell or claxon. We are fully moving away from timeware® providing this solution and are instead utilizing an external relay with a separate web interface that a customer can control themselves.

\*Point to note\*


This is to be self-installed by the customer. timeware® only recommends the devices to the customer and they purchase/fit themselves.

#### Recommended 'Bell Driver'

We currently recommend the X-401 Dual Relay and Input Module which can be purchased from www.controlbyweb.com

Full specification can be found here

https://www.controlbyweb.com/x401/



### **Specifications**

Compatible with any bell that ranges between 4v – 26v DC

Network connection required

Web interface used over your network to configure bell times

Self-Installed